


LeftTrigger RightTrigger

FrontPanel

PanelButtons

Speakers



Joystick

PowerButton

Motherboard

DiscMechanism



DC IN

MemoryCard

BackPanel



UMD

